




FAIRHAVEN SOUND™

Premium Quality Scallops

INSTALLATION INSTRUCTIONS FOR SCALLOP SIDING

The following installation guidelines refer to only one type of installation situation and are intended for use by the professional installer. These instructions are designed to help you plan and complete your siding project successfully.




DETERMINING THE NUMBER OF FAIRHAVEN SOUND SCALLOP COURSES

The finished gable should show one or two scallops visually balanced at the center of the peak. To determine this, you must first place a plumb line (Figure 1) from the roof peak and mark the left to right center and the bottom scallop starting height on the siding for the first row of scallops. The exposed height of one panel is 12-1/2". By dividing the peak height distance to your starting height by 12.5 you can determine the number of scallop courses needed to reach the peak.

Example: roof peak to siding is 72".


Divide 72 by 12.5 = 5.76 or 5 and 3/4 panels.

We recommend using full-height scallop panels and adjusting the starting point accordingly. In this instance, adjust the starting point to 75", which will accommodate 6 full-height courses and provide one full scallop at the roof peak.




INSTALLING THE SCALLOP STARTER STRIP

A scallop starter strip is recommended. It provides the proper clearance and rigidity necessary to provide a maintenance-free installation. This strip installs above the desired bottom position for the first row of scallops (Figure 2). Care should be taken to level this strip using the installed siding as a guide.



INSTALLING RIGID OR FLEXIBLE J-CHANNEL

Installing J-channel along the eaves is recommended as it provides a nice, finished appearance to your scallops installation.




INSTALLING THE FIRST COURSE OF SCALLOPS

Position the first scallop panel so one of the center top row of scallops is centered on the plumb line (Figure 3). **This will ensure that a single or double scallop will be visible at the peak.** Using the round nail hole, fasten the panel loosely with the appropriate fastener.

Working both ways, interlock panels into each other and the starter strip. Fasten each panel loosely for future expansion. Note: Take care to align the proper temperature lines located at the top right edge of each panel with the next panel for future expansion. Three lines are provided to cover all installation temperatures (Figure 4). At the eaves, match the roof slope by cutting the scallop panels and interlocking with each other and the J-channel.

Note: For best cutting results, use a fine-toothed plywood blade installed backward.


5



INSTALLING ADDITIONAL SCALLOP PANEL COURSES

Continue installing the scallop panels, staggering each course so joints are not lined up with the course below (Figure 5).

6



INSTALLING THE FINAL PEAK OF SCALLOPS

Trim the final scallop panel to the proper height. Then cut on each side of the panel to match the roof slope, centering the top scallops to match the roof peak (Figure 6). Hook this panel into the panel below and the J-channels and face nail using a color-matched head.

Note: Painting or staining of panels will void warranty.

Dealer Imprint Area—do not varnish



GENTEK BUILDING PRODUCTS, INC.
P.O. Box 110 • Akron, Ohio 44309
www.gentekinc.com

Make us a part of your home.